

Deluxe Raised Bed Instructions

N.B: The illustrations show a Deluxe 14 inch high bed being assembled. The 9 and 21 inch high beds use the same procedure with the appropriate single or triple tier construction.

9 INCH HIGH FLAT PACK CONTAINS:

2no. 23cm high treated timber side planks. 2no. 23cm high treated timber end planks,
4no. 11 x 11 x 23cm treated timber fixing posts with galvanized brackets . 32screws.

14 INCH HIGH FLAT PACK CONTAINS:

4no. 23cm high treated timber side planks. 4no. 23cm high treated timber end planks,
4no. 11 x11 x 36cm treated timber fixing posts with galvanized brackets . 64 screws.

21 INCH HIGH FLAT PACK CONTAINS:

6no. 23cm high treated timber side planks. 6no. 23cm high treated timber end planks,
4no. 11 x 11 x 54cm treated timber fixing posts with galvanized brackets . 96 screws.

All configurations are supplied with 8 mounting brackets and a right angled fixing guide.
The fixing guide is used to position the mounting brackets accurately on the corner posts.

